

VFR800

2014-present Part # 071966

Crossrunner

2015-present



1 x bracket	
2 x M6x16mm flange headed bolts	CBOL0251
3 x M6x12mm flange headed bolts	CBOL0123
3 x M6 Nyloc nuts	CNUT0200
1x M6 plastic washers	CWAS0221

Instructions:

Remove the rear brake hose mounting bolt on top of the chain-guard including the metal clip holding the brake hose and cable.
Then remove the two identical plastic caps on top of the swing-arm in front of the tyre, this is where the bracket attaches.

Attach the bracket to the outside of the hugger using the three M6 x 12mm nuts and bolts as show in the image above (hugger will not fit if bolts go on the other way)
fully tighten all these mountings.

Feed hugger over the tyre,

The jubilee clip holding the exhaust together may need moving round if hugger is touching it

loosely fit the hugger to the swing-arm using the two M6x16mm bolts then loosely attach on the chain-guard side replacing the hose and cable clip and using the original bolt removed,

Tighten the two bolts on the swing arm before tightening the chain-guard bolt fully.

Please note if the hugger looks closer to the tyre on one side and not the other please loosen all bolts connecting the hugger to the bike and make sure you tighten the swing-arm bolts fully before tightening the chain-guard bolt again.